
33CE008SH Flat Ceiling TV Mount with Shelf - Parts List



ITEM	PART NAME	DESIGNATION	QTY
1	Hardware pack (M-A to M-G)		1
2	Wall plate		1
3	NPT adapter	PP-0001	1
4	Plastic alignment washer	FB-0007	2
5	Hex bolt 5/16-18 x 3/4	HW-0001	2
6	Nylon locking nut 5/16-18	HW-0002	2
7	Pipe socket collar	PP-0002	1
8	Set screw 1/4-20 x 3/8	HW-0107	2
9	Hex wrench, 1/8 inch (for the set screws)	HW-0095	1
10	Lock bar		1
11	TV tilt rail assembly, left		1
12	TV tilt rail assembly, right		1
13	Hex wrench, 5 mm (for the leveling screws)		1
14	Glass shelf, hooks on the mount	33SH001	1

Shelf (item 14): the 33SH001's own parts list, included alongside this list, shows its pieces. Its backbone hooks over the wall plate and needs no fasteners.