



33TW003 Tilting TV Wall Mount - Parts List






















ITEM	PART NAME	LABEL	DESIGNATION	QTY
1	Hardware pack (M-A to M-G)			1
2	Wall plate			1
3	Lock bar			1
4	TV tilt rail assembly, left			1
5	TV tilt rail assembly, right			1
6	Hex wrench, 5 mm (for the leveling screws)			1
7	Wall screw, hex head M6 x 55 (into the anchor)	W-A		4
8	Concrete anchor, plastic, 10 x 44 mm (for the wall screw)	W-B		4
9	Flat washer, 6 mm (under the screw head)	W-C		4